



CALISTER

Vernazza Manual

Description of the display and control buttons

Display elements

Minute hand

Minute counter

Hour counter

Second counter

Hour hand

Second hand

Date

Control buttons

Push-button A

Crown

Push-button B

01

Chronograph: Basic function

(Start / Stop / Reset)

Example:

1 Start: Press push-button A.

2 Stop: to stop the timing, press push-button A once more and read the chronograph counters:
4h / 20 min / 38 sec

3 Zero positioning:
Press push-button B.
(The chronograph hands will be reset to their zero positions.)

05

Setting the time

1 Pull out the crown to position III (the watch stops).

2 Turn the crown until you reach the correct time 8:45.

3 Push the crown back into position I.

Please note:

* In order to set the time to the exact second, 1 must be pulled out when the second hand is in position «0». Once the hour and minute hands have been set, 2 must be pushed back into position I at the exact second.

02

Chronograph: Accumulated timing

Example:

1 Start: (start timing)

2 Stop: (e.g. 15 min 5 sec following 1)

3 Restart: (timing is resumed)

4 Stop: (e.g. 5 min 12 sec following 3)
= 20 min 17 sec
(The accumulated measured time is shown)

5 Reset: The chronograph hands are returned to their zero positions.

Please note:

* Following 5, the accumulation of the timing can be continued by pressing push-button A (Restart / Stop, Restart / Stop, ...).

06

Setting the date (quick mode)

1 Pull out the crown to position II (the watch continues to run).

2 Turn the crown anticlockwise until the correct date 11 appears.

3 Push the crown back into position I.

Please note:

During the date changing phase between approx. 08:30 PM and 12 PM; the date must be set to the date of the following day.

03

Chronograph: Intermediate or interval timing

Example:

1 Start: (start timing)

2 Display interval: e.g. 20 minutes 17 seconds (timing continues in the background)

3 Making up the measured time: (the chronograph hands are quickly advanced to the ongoing measured time.)

4 Stop: (Final time is displayed)

5 Reset: The chronograph hands are returned to their zero position

Please note:

* Following 5, further intervals or intermediates can be displayed by pressing push-button B (display interval / make up measured time, ...).

07

Setting the date/time

Example:

- Date / time on the watch: 11 / 1:25 AM

- Present date / time: 4 / 8:30 PM

1 Pull out the crown to position II (the watch continues to run).

2 Turn the crown anticlockwise until yesterday's date appears 3.

3 Pull out the crown to position III (the watch stops).

4 Turn the crown until the correct date 4 appears.

5 Continue to turn the crown until the correct time 8:30 PM appears.

6 Push the crown back into position I.

Please note:

* To set your watch to the exact second, please refer to the chapter entitled «setting the time».

** Please observe the AM/PM clock rhythm.

04

Adjusting the chronograph hands to zero position

Example:

One or several chronograph hands are not in their correct zero positions and have to be adjusted (e.g. following a battery change).

1 Pull out the crown to position III (all chronograph hands are in their correct or incorrect zero position.)

2 Keep push-buttons A and B depressed simultaneously for at least 2 seconds (the second counter hand rotates by 360° → corrective mode is activated.)

Adjusting the second counter hand

Single step A 1 x short

Continuous A long

Adjusting the next hand B

Adjusting the minute counter hand and the hour counter hand (mechanical coupled)

Single step A 1 x short

Continuous A long

3 Returning the crown to position I

Termination of the chronograph hands adjustment (can be carried out at any time).

08